



BATES EDC-100

Add the letter "L" to the end of part numbers for left handed reels

Key No	Part Number	Part Description	Key No	Part Number	Part Description	Key No	Part Number	Part Description	Key No.	Part Number	Part Description	Key No.	Part Number	Part Description
L1	EX-251	Nut Cap	G12	IN-029	Trip Ratchet Washer	F16	IN-018	Locking Plate Pinion Yoke	H8	EX-241	Click Spring	P14	EX-262	Brake Housing Screw
L2	EX-003	Washer	G13	***	Drive Gear	F17	IN-001	Pole-Pinion Yoke	H9	EX-242	Click Pin	S1	SP-011	Spool
L3	EX-004	Line Guide Pawl	G14	IN-106	Gear Clicker Ring	F18	IN-009	Pinion Yoke	H10	EX-243	Drag Star Cap	S2	EX-121	Spool Shaft Pin
L4	IN-012	E-Clip	G15	IN-035	Carbon Fibre Washer	F19	***	Pinion	H11	EX-244	Clip Ring	S3	BR-005	Spool Bearing
L5	IN-013	Washer	G16	IN-036	Drag "D" Washer	F20	IN-011	Spring-Pinion Yoke	H12	EX-245	Crank Arm Washer	S4	EX-266	Spool Shaft O-Ring
L6	BR-004	Bearing-Worm Shaft	G17	IN-034	Keyed Drag Washer	M1	EX-236	Gear Side Plate	H13	EX-246	Crank Arm		HL-011	Handle Assy'
L7	EX-066	Worm Shaft	G18	IN-065	Carbon Fibre Washer	M2	EX-252	Gear Side Plate Cap	H14	EX-023	Handle O-Ring			
L8	EX-201	Line Guide Carrier Ass'y	G19	IN-038	Drag Plate	M3	AR-001	One-Way Bearing	H15	EX-024	Handle Nut			
L9	EX-265	Worm Shaft Guide	G20	IN-037	Drag Click Spring	M4	IN-104	Locking Screw	H16	BR-014	Handle Bearing			
L10	EX-235	Line Guide Stabilizer Bar	G21	IN-042	Clutch Sleeve	M5	IN-105	Screw	H17	EX-247	Grip			
L11	IN-003	Idle Gear A	F1	FR-011	Frame	M6	IN-041	Clip Ring	H18	EX-248	Handle Post Screw			
L12	IN-004	Idle Gear Pole	F2	EX-234	Thumbbar Slider	M7	BR-001	Top Pinion Bearing	H19	EX-249	Grip Cap			
L13	IN-101	Locking Plate	F3	EX-235	Line Guide Stabalizer Bar	M8	EX-010	O-ring	P1	EX-250	Palm Sideplate			
L14	IN-104	Screw	F4	IN-014	Teflon Sliding Pad	M9	EX-015	Click Spring	P2	EX-253	Brake Dial Bracket			
G1	IN-023	SUS Ball	F5	IN-015	Form Washer	M10	EX-012	Spool Tension Pole	P3	EX-263	Click Spring			
G2	IN-022	Washer	F6	IN-107	Washer	M11	EX-013	Washer-Spool Tension	P4	EX-264	Click Pin			
G3	IN-021	Rubber Washer	F7	EX-097	Thumb Bar Screw	M12	EX-237	Spool Tension Cap	P5	EX-254	Brake Dial Knob			
G4	IN-010	E-Clip	F8	EX-233	Thumb Bar	M13	EX-001	Sideplate Screw	P6	EX-255	Click Pin			
G5	BR-001	Bottom Crankshaft Bearing	F9	BR-002	Bottom Pinion Bearing	H1	BR-002	Top Crank Shaft Bearing	P7	EX-256	Click Spring			
G6	IN-024	Crank Shaft Locking Plate	F10	IN-019	Bushing- Kick Lever	H2	EX-016	Washer	P8	EX-257	Brake Dial			
G7	IN-025	Crank Shaft Washer	F11	IN-020	Kick Lever	H3	EX-019	Spring D Washer	P9	EX-258	Brake Cam			
G8	IN-006	Crank Shaft Locking Screw	F12	IN-108	Bushing- Release Slider	H4	EX-020	Washer	P10	EX-259	Spool Cover			
G9	IN-026 (L)	Crank Shaft	F13	IN-017	Release Slider	H5	EX-238	Drag Star Spring Retainer	P11	EX-260	Washer			
G10	IN-027	Idle Gear B	F14	IN-007	Spring- Release Slider	H6	EX-239	Drag Star Spring	P12	BR-003	Palm Side Plate Bearing			
G11	IN-028	Trip Ratchet	F15	IN-008	Spring- Kick Lever	H7	EX-240	Drag Star	P13	EX-261	Chip Housing			

Part Key	Bearing Name	Bearing Size
L6	Line Guide	3 x 7 x 3
F9 / H1	Bottom Pinion/Top Crankshaft	8 x 12 x 3.5
M7 / G5	Top Pinion/Bottom Crankshaft	5 x 9 x 3
S3	Spool	5 x 11 x 4
P12	Brake Sideplate	3 x 10 x 4
M3	Anti-Reverse	10 x 14.75 x 8.5

GEARS	Ratio	Retrieve	Part number
Pinion Gear	6.3:1	Right	GRP-003
Drive Gear	6.3:1	Right	GRD-011
Pinion Gear	6.3:1	Left	GRP-003L
Drive Gear	6.3:1	Left	GRD-011L
Pinion Gear	7.1:1	Right	GRP-004
Drive Gear	7.1:1	Right	GRD-008
Pinion Gear	7.1:1	Left	GRP-004L
Drive Gear	7.1:1	Left	GRD-008L
Pinion Gear	8.1:1	Right	GRP-005
Drive Gear	8.1:1	Right	GRD-009
Pinion Gear	8.1:1	Left	GRP-005L
Drive Gear	8.1:1	Left	GRD-009L